



USER'S MANUAL



Model: BC-M375

37x15w 4in1 Led Zoom Moving Head Light

Package Includes:

- 1 x led zoom moving head light
- 1 x clamp
- 1 x power cable
- 1 x DMX cable

Please read this manual before use

● Features:

1. Voltage:AC 110-260V, 50/60Hz
2. Lamp:37pcs*4in1 15watt LED
3. Control mode:Auto/sound-active /master-slave /DMX512
4. TFT LCD display, the interface is gorgeous, improve the product level, the two menu structure and touch screen control mode, greatly improving the operation of the convenience, can be used to get started.
5. Menu language switch, the menu can be convenient to switch the Chinese or English.
6. Master and slave, when the DMX signal is disconnected, any one lamp can be used as a host, driven by other lamps.

● Menu structure

Menu	
Address	DMX Address(1-512)
Set	Run mode
	Channel mode
	Invert pan
	Invert tilt
	Hall crct
	Encoder crct
	Signal keep
	Screen saver
	Invert screen
	Update slave
	Language
	Load default
	EManual
2.pan fine	
3.tilt	
4.tilt fine	
5.XY speed	
6.zoom	
7.Dimmer	
8.Strobe	
9. LED-R	
10.LED-B	
11.LED-G	
12. LED-W	

	13. CTC
	14.color macro
	15.fixed pat
	16. effect
	17.effect speed
	18.effect-BG-R
	19.effect-BG-G
	20.effect-bg-B
	21.effect-BG-W
	22.reset
	Calib
Reset	Reset effect
	Reset scan
	Reset All
Note	Reset info
	DMX data
	Sensor info

● Channel table

Channel			Value	function
CH1	CH1	Pan	0-255	Pan 0-540 °
CH2	CH2	Pan fine	0-255	16 bit
CH3	CH3	Tilt	0-255	Tilt:0-215 °
CH4	CH4	Tilt fine	0-255	16 bit
CH5	CH5	Pan/tilt speed	0-255	Fast to slow
CH6	CH6	Zoom	0-255	10-60degree
CH7	CH7	Dimmer	0-255	0-100% dimmer
CH8	CH8	strobe	0-3	dimmer
			4-63	Strobe slow to fast
			64-66	dimmer
			67-126	Pulse strobe slow to fast
			127-129	dimmer
			130-189	Strong strobe slow to fast
			190-192	dimmer
			193-252	Random strobe
253-255	dimmer			
CH9	CH9	Red	0-255	dark-bright
CH10	CH10	Green	0-255	dark-bright
CH11	CH11	Blue	0-255	dark-bright
CH12	CH12	White	0-255	dark-bright
CH13	CH13	Color temperature	0	No effect
			1-255	8000K-2500K
CH14	CH14	Color	0	No effect

		temperature	1-247	Built-in color
			248-255	Rainbow effect
CH15	CH15	Pattern	0-9	No effect
			10-19	Pattern 1
			20-29	Pattern 2
			30-39	Pattern 3
		
			240-249	Pattern 24
			250-255	Pattern 25
CH16	CH16	Dynamic effect	0-9	No effect
			10-19	Effect1(with color channel)
			20-29	effect2(with color channel)
			30-39	effect3(with color channel)
		
			120-129	Effect12 (with color channel)
			130-139	Effect 13
		
			240-249	Effect 24
250-255	Effect 25			
CH17	CH17	Effect speed	0-64	Effect index
			65-159	Effect rotating
			160-255	Effect count -rotating
CH18	CH18	Back red	0-255	ch15/ch16 by back red
CH19	CH19	Back green	0-255	CH15/CH16 by back green
CH20	CH20	Back blue	0-255	CH15/CH16 by back blue
CH21	CH21	Back white	0-255	CH15/CH16 by back white
CH22	CH22	Reset	0-239	No effect
			240-250	All reset in 5 seconds
			251-255	No effect
	CH23	LED1R	0-255	Pixel 1 red
	ch24	LED1G	0-255	Pixel 1 green
	CH25	LED1B	0-255	Pixel1 blue
	CH26	LED 1W	0-255	Pixel 1 white
	CH27	LED 2R	0-255	Pixel 2 red
	0-255
	CH50	LED 7w	0-255	Pixel 7 white

● Cleaning

As the smoke and dust corrosion, internal and external vision lens must be cleaned out to make the light output power optimization.

1. Use the glass cleaner and soft cloth to clen the package.
2. Every 20 days, use the glass cleaner and soft cloth to clean the external lens.
3. When you insert the power is always to ensure that every part of the product dry.

When Fixtures run, require regular cleaning according to the different environments.

● Troubleshooting

The following are some common problems encountered and the solutions when the customers use it:

1. For there is no response to DMX
2. Check the DMX cable is properly connected (pin3 as follows: "hot", in other DMX devices, pin2 are also as follows: "hot" means.
3. For the voice made no reply
4. Sound is too small or too high-profile voice can not make it up and running. If this problem persists, please contact your vendor for help.

● Maintenance

5. Please keep the light in dryness and avoiding use in wet place.
6. Using intermittently can be extended the life.
7. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
8. Please do not wipe the crust using organic menstruum avoiding to damage the product.

● Statement

The product has well capability and intact packing when leave factory. All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change.

ShenZhen BECEN Stage Equipment Co., Ltd

Add: Room 501, 5th floor, Yishenrong industrial park, Xihuan road,

ShaJing, BaoAn, Shenzhen, GuangDong, China

Website: www.szbecen.com

www.becenstage.com

Tel: 86-13410588234

Email: sales01@szbecen.com

sales02@szbecen.com



Scan it to get more info.